www.cherubtechnology.com

G-TONE
Owner's Manual
Acoustic Guitar Preamp

GS-1 Acoustic Guitar Preamp



1. When the output line is connected to GS-1, it will start automatically. When the output line is pulled out, it will shut down automatically.
2. GS-1 has 4-band equalizer. Push BASS to adjust low frequency. Push MIDD to adjust middle frequency. Push TREB. to adjust high frequency. Push PRES. to adjust ultrahigh frequency. Push VOL. to adjust main volume.
3. Press PHASE to turn on/off phase function.
4. When the BATT. lights, please replace the batteries as soon as possible.

❋Download **Installation Guide&Cut-out Template**
From **www.cherubtechnology.com**

GS-1 箱琴EQ系列



1、当将输出线连接好后GS-1自动启动，输出线拔出后GS-1自动关闭。
2、GS-1有四段EQ均衡器，BASS推钮调节低频；MIDD推钮调节中频；TREB.推钮调节高频；PRES.推钮调节超高频，VOL.旋钮调节总音量。
3、按PHASE按键开启或关闭PHASE功能。
4、BATT.灯亮时表示电池电量不足，请尽快更换新电池。

❋ **安装说明和切口模板**
请到www.cherub.cn下载

More Musical, More Scientific,and More for YOU!
CHERUB TECHNOLOGY CO.,LTD